LEADING vs. TRAILING shoe configurations.



Above: Leading Shoe – Inboard Mounted (Sprocket toward Engine) (Cover Removed for Clarity)



Above: Trailing Shoe - Inboard Mounted (Sprocket toward Engine) (Cover Removed for Clarity)



Above: Leading Shoe – Outboard Mounted (Sprocket away from Engine) (Drum Removed for Clarity)



Above: Trailing Shoe – Outboard Mounted (Sprocket away from Engine) (Drum Removed for Clarity)

DANGER